

DESIGNER PANELS INSTRUCTIONS

1. Apply glue to the back of the panel in a zigzag pattern.
We strongly recommend the use of our adhesive where the panels join. This will assist in maintaining the integrity of the installation by preventing any possible flexing or separation of the product due to extreme ambient temperature and humidity changes once the installation is complete. It will also insure that your newly installed panels remain water/weatherproof.
2. Make sure the panel is level and fasten the panel to the wall with screws periodically in the mortar lines and recess the screw head.
3. For the next panel, repeat steps 1 and 2, leaving a small gap wide enough to put the foam rope into.



4. After all panel in the first row are complete, glue foam rope into seams.
5. Make sure to keep the panels level. You can use a chalk line (or pencil lines) on your wall to make sure the panels are staying straight.
6. Now you can start installing panels on the next row, once again, leave a gap for wide enough for the foam rope. For a seamless look, offset each row by one half sheet. This will make it impossible to notice any seams
7. Repeat Steps 1, 2 & 3.
8. Caulk all the seams.

